
EEC-IV to Microsquirt Adaptor V.03
fscotthall@comcast.net © 2006
ACCEL
WARMUP
IGNITION
J4
J3
J1
J2
U1
C1
R8
R7
12V
5V
Q1
Q2
R1
R2
R3
R4
C2
D1
D5
R6
R9
EEC SIGNALS
CAM & CRANK
PIP
OUT POINT
MAX 4000
GND
+5V
+12V
+12V
+5V
GND
TACH
TACH
ASCSH
ASCSH
ACCEL
ACCEL
WARM
WARM
GEAR
GEAR
IGN1
IGN2
TACH
TACH
GND
GND
notch